



We want to be with you every step of the way. So much so, that we've created an exclusive Spotify playlist for your renovation and for you. Let the rhythm never stop!

**IMAGINE.
CREATE.
ENJOY.**



APPLICATION GUIDE
STEP BY STEP



If Gaudi had this guide, the Sagrada Familia would have been finished a looong time ago.



RENOVATION
WITHOUT
BUILDING WORK

You've been imagining it for a while. And now it's time to get creative!

Don't worry about anything because this kit contains eveeerything you need to do the renovation yourself, the one you've been dreaming about for a while.

We could tell you that "in the blink of an eye" or "in no time at all" you'll be enjoying that new corner of your home, but the truth is, with Smartcret, explanations and even sayings are unnecessary.

Just enjoy the process and the excitement of unveiling. We'll take care of the rest.

For example, we'll guide you through the step-by-step process for your renovation.

Let's get started!

www.smartcret.com

01

TIME TO CLEAN UP!



For the result to be as beautiful and perfect as you want, it's essential that the surface is free of dust and grease.

So, let's cleeeean.

Then, take the protective adhesive tape and outline the surface where you'll be applying it.

02

CHOOSE BETWEEN

02A

Absorbent surfaces
(Drywall, plaster, etc.)

02B

Non-absorbent surfaces
(Marble, terrazzo, tiles, etc.)



Well bonded surfaces

It's time to prepare the surface to ensure proper adhesion of the microcement. And for that, we have Smart Primer ABS.

Take the roller and the handle, attach them together, and apply **one layer of Smart Primer ABS** (pour the product into a tray for added convenience).

Wait for approximately 30 minutes for it to dry, and immediately clean the roller to prolong its lifespan.



Say goodbye to the joints

Take **Smart Jointer** and fill the joints of the surface with **one layer**. You can do it with a spatula or trowel.

Go for a run, sleep, or take care of that task you've been procrastinating while you wait for it to **dry for 24 hours**.

Then, sand the surface with **sandpaper, grain size 40***. You'll see the sandpaper grain on the velcro part. Just attach it to the sanding glove and start sanding, sanding, and sanding.

*If you purchased our toolkit, you'll find the glove there :)



Unity is strength

It's time to prepare the surface to ensure proper adhesion of the microcement. And for that, we have Smart Primer GRIP.

Use the spatula to manually mix the product.

Take the roller and the handle, attach them together, and apply **one layer of Smart Primer GRIP** (pour the product into a tray for added convenience).

Wait for 2-4 hours for it to dry, and immediately clean the roller with water after use to prolong its lifespan.

03

THE HEART OF THE RENOVATION



Do you remember the dance from the song "Mayonesa"?

Well, remove with that rhythm and with the help of the **Smart Base** spatula.

Then, **apply 2 layers with the steel trowel** (use the spatula to apply the product on the trowel) and remove the adhesive tape.

Leave 6 hours between each layer for proper drying.

Sand the surface with **sandpaper, grain size 40***. You will see the sandpaper grain on the Velcro part. Just attach it to the sanding glove and start sanding, sanding, and sanding.

*If you have purchased our toolkit, you will find the sandpaper there :)

04

LIKE PUDDING, SHALL WE REPEAT?



Dance again and mix **Smart Liso** with the spatula!

Place the protective tape back on and apply **2 layers with the rubber trowel**, or if you want a different type of finish, you can apply it with the steel trowel.

Remove the tape and **let it dry for 6 hours** between each layer.

Sand after each layer with **sandpaper, grain size 220**.

05

PROTECTION ABOVE ALL



In your order, you have chosen the desired finish (matte or satin), but also much more: **Smart Varnish** will protect the surfaces to make them look perfect.

After placing the adhesive tape on the surface, simply apply **3 layers** in a single day and allow **4 hours of drying** time between each layer.

We recommend sanding the first and second layers with **sandpaper, grain size 400**.

IMAGINE. CREATE. ENJOY.

And voila! You have just renovated that space in your home in just a few days and easily.

Now, enjoy it, make the most of it, and if you feel like it, show your work to the world :)

At Smartcret, we can't wait to see the result.

Icon guide



*All sandpaper grits indicated in this step-by-step guide are for manual sanding (not machine sanding).